


## T.I.P. Rural Electric Cooperative



## Wind and Solar Policies and Procedures

- 1. Fill out application form and pay appropriate application fee.
- 2. Sign the form- "Agreement for Electric Service for Qualifying Co-generation and/or Small Power Production Facilities".
- 3. Show proof of insurance as prescribed in the "Agreement for Electric Service for Qualifying Co-generation and/or Small Power Production Facilities". section B part i.
- 4. The interconnection shall be provided with a switch that provides a visible break or opening. The switch shall be capable of being padlocked in the open position.
- 5. T.I.P. would like you to install a meter base for the distributed generation to register KWH's for the distributed generation only. (This meter is at no cost to you and is for informational purposes only).
- 6. If you want to sell KWH's back to TIP/CIPCO, a bi-directional meter needs to be installed where your main meter is now.
- 7. The unit cannot be interconnecting with T.I.P. Rural Electric Cooperatives lines until all paper work is completed and unit and wiring is inspected.

## T.I.P. RURAL ELECTRIC COOPERATIVE

Cole Calkins Staking Technician/Member Service